


## REUSABLE SPOOL INSTRUCTIONS

### After the zipper is used:

1

Simply pull the Cord-Lock to begin disassembly of the spool.

Break down empty spools into nested components, reducing the in-plant storage space needed.




4

Returned zipper spools are inspected and thoroughly cleaned. Damaged zipper spools are recycled and manufactured into new spools.

2

3

Repackage the components separately into the boxes in which they were shipped. Disassembled spools are sent to our washing facility at no charge to you.  
**Note: All components must be packaged and shipped according to instructions on reverse side.**



Once you re-order, full spools are shipped back to you ready for re-use!



# GREEN

SPOOL PROGRAM

For more information contact your Fresh-Lock sales representative.